

# BITE RIM & SETUP TRYIN PROTOCOL



## ***APPOINTMENT 1: MASTER CASTS***

1. Scan full upper or stone cast (palate, vestibule, etc.)
2. Scan full lower or stone cast (vestibule, retro-molar pads, etc.)

### ***LAB:***

1. Print upper and lower models
2. Fabricate upper/lower wax rims

## ***APPOINTMENT 2: SETTING VDO***

1. Use wax rims to take the bite  
[Accurate CR bite recommended when applicable]
2. Mark midline, incisal edge, etc.
3. Take full face photos with the rims to assist in setting the teeth

### ***LAB:***

1. Set teeth on the wax rims based on the above records
2. Add radiographic markers onto setups

## ***APPOINTMENT 3: FINAL RECORDS***

1. CBCT with setups
2. Bite with setups
3. PICTURES with setups